

**INSTALLATION INSTRUCTIONS FOR
PUTCO SKINS (FITTED BED CAPS)**

**INSTRUCCIONES PARA LA INSTALACIÓN DE
REVESTIMIENTOS DE CAMIONETAS PUTCO
(CUBIERTAS AJUSTABLES PARA LA PLATAFORMA DE CARGA)**

**INSTRUCTIONS D'INSTALLATION DES REVÊTEMENTS POUR
CAMIONNETTES PUTCO (PROTECTION AJUSTÉE POUR LE PLATEAU)**

Congratulations on your purchase of a high quality Putco product. Should you need any application or technical assistance, feel free to call us at: 800-247-3974 Monday-Friday 8:00 A.M. - 5:00 P.M. Central Standard Time. Contact your Putco Dealer for other quality accessories. Putco Inc., 216 West First Street, Story City, Iowa 50248.

Felicitaciones por su compra de un producto de alta calidad Putco. Si necesitase cualquier asistencia técnica o información sobre su aplicación, por favor llámenos al número de teléfono: 800-247-3974, de lunes a viernes de 8:00 de la mañana a 5:00 de la tarde (hora central). Contacte con su concesionario Putco para otros accesorios de calidad. Putco Inc., 216 West First Street, Story City, Iowa 50248.

Félicitations pour votre achat d'un produit de haute qualité Putco. Pour tout renseignement sur son utilisation ou toute assistance technique, ne pas hésiter à nous téléphoner au: 800-247-3947, du lundi au vendredi, de 8h à 17h, heure normale du Centre. Contacter votre dépositaire Putco pour obtenir tout autre accessoire de qualité. Putco Inc., 216 West First Street, Story City, Iowa 50248.

Please read all instructions before beginning installation.

NOTE: All materials must be clean and at least 60° F for proper adhesion.

NOTE: Vehicles with plastic bed rail protectors. You must first remove the plastic protector starting at the rear of the vehicle, pull up on inside edge until it comes loose.

Some force may be needed. Damage will occur to plastic protector when removing.

For Tape Installation

- Step 1: Using the alcohol pads, wipe the entire top surface of the truck side bed to remove any oils, waxes, dirt, etc. The surface must be clean for the 3M tape to adhere properly.
- Step 2: Place the Putco Skins on the top of the truck side beds to check for proper fit.
- Step 3: We have pre-positioned the 3M tape to the bottom of the Putco Skins. Remove the plastic backing from the tape and install the Putco Skins to the top of the side bed. **WARNING:** Once the tape comes in contact with the vehicle it will adhere immediately and you will not be able to adjust it. Be sure to have everything aligned before placing on vehicle. **This is a two person job!**

NOTE: Start at rear of vehicle, press on the outside edge down on the Putco Skin. Work your way to the front of the box.

FINAL NOTE:

TO MAINTAIN A "JUST OUT OF THE PACKAGE LOOK"

PUTCO RECOMMENDS

APPLYING A HIGH QUALITY AUTOMOTIVE WAX TO ALL
OUR PRODUCTS AFTER INSTALLATION.